



UNIVERSAL ARMRESTS

INSTALLATION INSTRUCTIONS

01-026, 01-027, 01-028

01-035, 01-036

INCLUDED:

- 2 UNIVERSAL ARMRESTS
- 2 TEMPLATES
- HARDWARE PACK



Cut out templates. Place templates on rear seat kit side bars, making sure that templates are centered side to side on bar. Front to back placement is by personal preference. Drill holes using a 5/16" drill bit. Mount armrest using hardware pack.



HARDWARE PACK

- (4) 6MM X 40MM SHOULDER HEX BOLTS
- (4) FLAT WASHERS
- (4) SPLIT WASHERS

TEMPLATE 1



TEMPLATE 2