


# ELECTRICAL 2



Ref. No.	Part Number	Description	Qty	Remarks
1	J55-H2122-00-00	SEAT, BATTERY .....	1	
2	J17-82133-00-00	SCREW, FITTING .....	2	
3	J55-H2136-00-00	PLATE, BATTERY .....	1	
4	92990-06200-00	WASHER .....	2	
5	95701-06300-00	NUT, NYLON .....	2	
6	J55-H2115-02-00	WIRE, PLUS LEAD .....	1	
7	861-82361-00-00	CLAMP, CORD .....	1	
8	J55-H2116-00-00	WIRE, MINUS LEAD (J38-82116-00) .....	1	
9	J55-H2117-00-00	WIRE, LEAD .....	1	
10	J38-82105-00-00	WIRE HARNESS .....	1	
11	J38-82590-21-00	WIRE HARNESS ASSEMBLY (J38-82590-20) .....	1	
12	J55-H7196-00-00	TUBE 1 (J38-87196-00) .....	1	
13	J55-H7197-00-00	TUBE 2 (J38-87197-00) .....	1	
14	90465-06038-00	CLAMP .....	1	
15	90464-23041-00	CLAMP .....	1	
16	J38-82305-20-00	IGNITOR UNIT ASSEMBLY 1 ..	1	
17	J38-8553A-00-00	STAY UNIT .....	1	
18	95811-06010-00	BOLT, FLANGE .....	2	
19	J38-82310-20-00	IGNITION COIL ASSEMBLY ...	1	
20	98511-05020-00	SCREW, PAN HEAD .....	2	
21	92990-05100-00	WASHER, SPRING .....	2	
22	J38-82318-00-00	WIRE, SUB-LEAD .....	1	
23	8K1-82370-20-00	PLUG CAP ASSEMBLY (WITH RESISTOR) .....	1	
24	J38-82372-00-00	SEAL, plug cap .....	1	
25	1E6-82150-00-00	FUSE HOLDER ASSEMBLY ...	1	
26	1E6-82151-00-00	. FUSE (10A) .....	2	
27	1E6-82150-00-00	FUSE HOLDER ASSEMBLY ...	1	

CONTINUED ON NEXT FRAME ►

